

## Ness IDTeck Accessories

### DATA CONVERTERS

<b>SPECIFICATIONS</b>	<b>101-122</b>
<b>CPU</b>	Ubicom SX52BD/PQ 50Mhz (8-Bit MicroController, 50MIPS)
<b>MEMORY</b>	4K Bytes Flash Program Memory 256 Bytes SRAM Data Memory 2KBytes Flash Memory (Web Page & System Parameter)
<b>NETWORK CONNECTION</b>	10 Base-T Ethernet Interface
<b>NETWORK PROTOCOL</b>	HTTP, TCP/UDP, IP/ICMP/ARP IEEE 802.3 (Ethernet)
<b>UTILITY SOFTWARE</b>	NetEye Setup Program (Windows98/ME/NT/2000) NetEye Search, IP Setup, Built-In Test Result Display, Web Page Upload on the Network Loop Test Program (Windows95/98/ ME/NT/2000)
<b>POWER REQUIREMENTS</b>	6-9V DC



#### 101-122 NetEye 1000SA

- External Serial to Ethernet Converter
- Miniaturized module device for Network connectivity
- TCP/IP Kernel and Ethernet installed
- RS232, RS422, RS485 (optional) supported

<b>SPECIFICATIONS</b>	<b>101-121</b>
<b>COMMUNICATION</b>	RS-232 (DB-9Pin, Male) Maximum distance, 20m
<b>LED INDICATORS</b>	Power / TXD / RXD
<b>COMMUNICATION SPEED</b>	115.2 KBPS
<b>POWER SUPPLY</b>	240V AC



#### 101-121 CNP200A

- RS232 signal converter to RS422/485
- Multi drop or Point to Point Communication type
- Built in Surge Protector
- Built in LED (Power, Transmit, Receive)

[www.ness.com.au](http://www.ness.com.au)

© 2004 Ness Security Products Pty Ltd ABN 28 069 984 372  
Photographs are used for illustrative purposes only. Design and specifications may vary.



Access Control Products

**SYDNEY**  
02 8825 9222  
sales@ness.com.au

**MELBOURNE**  
03 9875 6400  
nessmelb@ness.com.au

**BRISBANE**  
07 3399 4910  
nessbris@ness.com.au

**PERTH**  
08 9328 2511  
nessper@ness.com.au

**ADELAIDE**  
08 8277 7255  
aquavia@cobweb.com.au

**NZ (NFS SECURITY)**  
+64 9 573 0401  
sales@nfs.co.nz